

Back

Magelis XBT GT User Manual

35010372 01 eng 2.0



Table of Contents



	Safety Information	7
	About the Book	9
Part I	XBT GT Panels	11
	At a Glance	11
Chapter 1	Overview	13
	At a Glance	13
	XBT GT Series of Panels	14
	Package Contents	17
	Series XBT GT Panels and Standards	19
	CE Marking Notes	20
Chapter 2	XBT GT Device Connectivity	21
	At a Glance	21
	System Design	22
	Accessories	24
Chapter 3	Specifications	31
	At a Glance	31
3.1	General Specifications	33
	At a Glance	33
	Electrical Specifications	34
	Environmental Specifications	35
	Structural Specifications	37
3.2	Functional Specifications	38
	At a Glance	38
	Display	39
	Memory, Clock, and Touch Panel	42
	Interface	43
3.3	Interface Specifications	45
	At a Glance	45
	Specifications of Serial Interface COM1	46
	Specifications of Serial Interface COM2	51


	Other Interfaces	52
3.4	Part Numbers and Functions	53
	At a Glance	53
	Parts Identification and Functions	54
	Terminal Configuration Switches	58
3.5	Dimensions	61
	At a Glance	61
	XBT GT1000 Series Dimensions	62
	XBT GT2000 Series Dimension	65
	Panel Cut dimension	69
	Installation Fasteners	70
Chapter 4	Installation and Wiring	73
	At a glance	73
4.1	Installation	75
	Installation Procedures	75
4.2	Wiring Precautions	82
	At a glance	82
	Connecting the Power Cord	83
	Connecting the Power Supply	86
	Grounding	88
	Input/Output Line placement	90
4.3	Tool Port Connector	91
	At a Glance	91
	Presentation	92
	USB Data Transfer Cable (XBT ZG925) - USB Driver Installation	93
4.4	Ethernet Cable Connector	96
	Presentation	96
4.5	CF Card	98
	CF Card Installation and Removal	98
4.6	USB Port	101
	At a Glance	101
	Presentation	102
	USB Data Transfer Cable (XBT ZG935) - USB Driver Installation	103
	USB Cable Clamp	106
Part II	Setting and Debugging	109
	At a Glance	109
Chapter 5	Settings	111
	At a Glance	111
5.1	XBT GT Settings	113
	At a Glance	113
	Types of Settings	114
	Offline Settings	115
	System Settings	118

Chapter 6 Troubleshooting 121
At a Glance 121
Troubleshooting Checklists 122
Self Test List 126

Chapter 7 Maintenance 129
At a Glance 129
Regular Cleaning 130
Periodic Check Points 131
Replacing the Backlight 132

Index 133

Safety Information



Important Information

Note

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation, which **will result** in death, serious injury or equipment damage.

WARNING

WARNING indicates a situation presenting risks liable to **provoke** death, serious injury or equipment damage.


CAUTION

CAUTION indicates a potentially hazardous situation, which, **can result** in personal injury or equipment damage.

Electrical equipment should be serviced only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.

© 2005 Schneider Electric. All Rights Reserved.

About the Book



At a Glance

Document Scope This manual describes how to use the Magelis XBT GT device.

Validity Note Using the Magelis XBT GT device.

Revision History

Rev. No.	Changes
3	Post Safety

User Comments We welcome your comments about this document. You can reach us by e-mail at techpub@schneider-electric.com

XBT GT Panels



At a Glance

Overview

This part presents XBT GT Panels.

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	Overview	13
2	XBT GT Device Connectivity	21
3	Specifications	31
4	Installation and Wiring	73

Overview



At a Glance

Overview

This chapter presents series of XBT GT Panels and devices connectable to the XBT GT.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
XBT GT Series of Panels	14
Package Contents	17
Series XBT GT Panels and Standards	19
CE Marking Notes	20

XBT GT Series of Panels

Introduction

The following presents the XBT GT series of Human Machine Interface products. These products are graphical touchscreens and have an operating voltage of 24 Volts DC. The products offered in this series have various features and benefits listed below:

- Screen size,
- Resolution of the screen,
- Technology and color of the screen,
- Communication.

XBT GT Part Number

The following table presents the different XBT GT Products:

Part number	Screen size (inch/cm)	Resolution Pixel	Mono/Color	Screen technology	Video	Ethernet
XBT GT1100	3.8"/9,6	QVGA	Amber	STN	No	No
XBT GT1130	3.8"/9,6	QVGA	Amber	STN	No	Yes
XBT GT2110	5.7"/14,4	QVGA	Blue Mode	STN	No	No
XBT GT2120	5.7"/14,4	QVGA	Monochrome	STN	No	No
XBT GT2130	5.7"/14,4	QVGA	Monochrome	STN	No	Yes
XBT GT2220	5.7"/14,4	QVGA	Color	STN	No	No
XBT GT2330	5.7"/14,4	QVGA	Color	TFT	No	Yes

- STN: Scan Twisted Neumatic also known as passive matrix.
- TFT: Thin Film Transistors also known as active matrix.

Note: To avoid potential data loss, be sure to back up the XBT GT unit's screen data regularly.

 **WARNING****RISK OF UNINTENDED EQUIPMENT OPERATION**

- Do not use the XBT GT as the only means of control for critical system functions such as motor start/stop or power disconnect
- Do not use the XBT GT as the only notification device for critical alarms, such as device overheating or overcurrent
- Do not use the XBT GT with aircraft control devices, aerospace equipment, central trunk data transmission (communication) devices, nuclear power control devices, or medical life support equipment, due to the reliability requirements of these industries
- Do not use the XBT GT as the only means of control for critical system functions such as motor start/stop or power disconnect

In the event of backlight or other XBT GT failure, it may be difficult or impossible to identify a function. Emergency stop, fuel shutoff, or any function that may present a danger if not immediately executed must be provided independently of the XBT GT. In addition, the machine control system design should take into account the possibility of the backlight failing and the operator being unable to control the machine, or making errors in the control of the machine.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

**Critical systems,
alarms and
handling
Requirements**

Critical alarm indicators and system functions require independent and redundant protection hardware and/or mechanical interlocks.

 **WARNING****RISK OF BURNS OR EQUIPMENT DAMAGE**

Wait at least 10 seconds before restoring power to the XBT GT after turning it off. Switching the XBT GT off and on too quickly can result in overheating that leads to personnel burn hazards or equipment damage.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Handling the LCD panel

The following characteristics are specific to XBT GT's LCD unit and shall not be considered as defects:

- LCD screen may show unevenness in the brightness of certain images or may appear different when seen from outside the specified viewing angle. Extended shadows, or "Crosstalk" may also appear on the sides of screen images.
- LCD screen pixels may contain black and white colored spots and color display may seem to have changed.
- When the same image is displayed on the XBT GT unit's screen for a long period, an afterimage may appear when the image is changed. If this happens, turn OFF the XBT GT, wait 10 seconds and then restart the unit.

Note: Change the screen image periodically and try not to display the same image for a long period of time.

WARNING

RISK OF SERIOUS EYE AND SKIN INJURY FROM DAMAGED OR LEAKING LCD PANEL

- Do not touch nor handle an XBT GT whose LCD panel appears damaged or seems to be leaking.
- Do not use sharp objects or tools in the vicinity of the LCD touch panel or to operate its buttons.
- Handle the LCD panel carefully to prevent puncture, bursting, or cracking of the panel material.

The LCD panel's liquid contains an irritant. If the panel is damaged and any of this liquid is in contact with your skin, immediately rinse the area with running water for at least 15 minutes. If the liquid gets in your eyes, immediately rinse your eyes with running water for at least 15 minutes and consult a doctor.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Package Contents

Introduction


The following items are included in the XBT GT's package. Before using the XBT GT, please make sure that all items listed here are present:

- XBT GT Unit,
- Power Plug,
- Quick Reference Guide,
- Screw Installation Fasteners (x4),
- Installation Gasket,
- USB Holder (except for XBT GT1000 series),
- USB Cable Clamp (except for XBT GT1000 series).

This unit has been carefully packed with special attention to quality. However, should you find anything damaged or missing, please contact your local XBT GT distributor immediately.

XBT GT Package Contents

The following shows the XBT GT Package Contents:




XBT GT1000 series




XBT GT2000



Installation Gasket



Power Plug



Screw Installation Fastener (x4)



Installation Guide



**USB Holder
(Not supplied with XBT GT1000 series)**




**USB Cable Clamp
(Not supplied with XBT GT1000 series)**

Revision

You can identify the product version (PV), Revision level (RL), and the Software version (SV) from the product label sticker pasted on the XBT GT unit.

The following diagram show a typical representation of label sticker:



Series XBT GT Panels and Standards

Introduction

The XBT GT series of panels are UL/C-UL listed and CSA Certified.

These units have been developed to conform with the following standards:

- UL 508 for Industrial Control Equipment,
- UL 1604 Electrical Equipment for Use in Class I and Class II Division 2 and Class III Hazardous Locations,
- UL 60950 Standard for Safety of Information Technology Equipment,
- CAN/CSA-C22.2, No.14 and No.213 Industrial Control Equipment Miscellaneous Apparatus - For Hazardous Locations.

UL1604 Conditions of Acceptability and Handling Cautions:

DANGER

RISK OF EXPLOSION AND EQUIPMENT DAMAGE

- **Compatibility:** Power, input and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods - Article 501- 4(b) of the National Electrical Code, Groups A, B, C and D Hazardous, NFPA 70 or as specified in section 18-152 of the Canadian Electrical Code for installations within Canada and in accordance with the authority having jurisdiction.
- Confirm that the location is not subject to any risk of explosion before connecting or disconnecting equipment, replacing or wiring modules.
- Confirm that the power supply has been turned OFF before disconnecting, replacing or wiring modules.
- Before turning ON, sweep front panel with a damp cloth.

Failure to follow this instruction will result in death, serious injury, or equipment damage.

CE Marking Notes

Introduction

The XBT GT units are CE marked, EMC compliant products.

These units also conform to EN55011 Class A, EN61000-6-2 directives. For detailed CE marking information, please contact your local XBT GT distributor.

Environment	Standards
Compliance with standards	IEC 61131-2, IEC61000-6-2, CISPR11(Class A) UL 508, CSA C22.2, n°14 & n°213
Product certification	CE, UL/cUL, CSA, Class 1 Div 2 T4A or T5 (UL & CSA)
Operating temperature	0°C + 50°C (32°F 122°F)
Storage temperature	-20 °C + 60°C (-4°F 140°F)
Protection (front panel)	IP 65 - (IEC 60529) Enclosure Type 4, 4X Indoor use with Screw Installation Fasteners only.
Protection (rear panel)	IP 20 - (IEC 60529)
ESD withstand	IEC 61000 - 4 - 2 6kV, contact, 8kV air
Radiated radio frequency electromagnetic field	IEC 61000 - 4 - 3 10 V / m
Electrical fast transient burst	IEC 61000- 4 - 4 2kV (power supply and I/O) 1kV other ports
High Energy Surges	IEC 61000 - 4 - 5 1kV (Differential Mode on power supply) 2kV (common mode on power supply)
Shocks	IEC 60068 - 2 - 27 1/2 sinusoidal pulse for 11ms, 15 g on 3 axes
Vibration	IEC 60068 - 2 - 6 3.5mm 5 Hz to 9 Hz 1 g, 9 Hz to 150 Hz
Pollution Degree	Pollution Degree 2

XBT GT Device Connectivity



At a Glance

Introduction

This chapter presents for each XBT GT unit the equipment connectable to it.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
System Design	22
Accessories	24


System Design

Introduction

The following diagrams represent the main selection of equipment connectable to the XBT GT.

XBT GT1000 series Edit Mode Peripheral


The following illustration displays XBT GT1000 series edit mode peripheral:
XBT GT1000 series Unit Personal Computer



(1) Not available on XBT GT1100

XBT GT2000 series Edit Mode Peripheral

The following illustration displays XBT GT2000 series edit mode peripherals:
XBT GT2000 series Personal Computer




(1) Not available on XBT GT2110/2120/2220

(2) Not available on XBT GT2110

XBT GT1000 Series Run Mode Peripheral


The following illustration displays XBT GT1000 Series run mode peripherals:



(1) Not available on XBT GT1100

XBT GT2000 series Run Mode Peripheral

The following illustration displays XBT GT2000 series run mode peripherals:



(1) Not available on XBT GT2110/2120/2220

(2) Not available on XBT GT2110

(3) Bar code Reader validated with Gryphon range of Datalogic

(4) Printer validated with EPSON and HP model: it is available on Vijeo Designer documentation

Accessories

Introduction

The following accessories are used with XBT GT.

XBT GT Serial Interface Item

The following table presents the Serial Interface item used with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT Z915	Cable	Connect XBT GT COM1 port to a serial printer.	XBT GT2000
XBT Z9780	XBT Z Cable	Connect XBT GT1000 COM1 port or XBT GT2000 COM2 port to Premium, Micro, Twido PLC	XBT GT1000/ GT2000
VW3A8306	XBT Z Cable	Connect XBT GT1000 COM1 port or XBT GT2000 COM2 port to derivation box TSXSCA62	XBT GT1000/ GT2000
VW3A8306R10	XBT Z Cable	Connect XBT GT1000 COM1 port or XBT GT2000 COM2 port to ATV Drives or to Hub LU9GC3	XBT GT1000/ GT2000
STBXCA4002	XBT Z Cable	Connect XBT GT COM1 port to Advantys STB	XBT GT2000
TSXPCX1031	XBT Z Cable	Connect XBT GT COM1 port to Premium, Micro, Twido	XBT GT2000
XBT ZG909	XBT Z Adapter	Cable adapter COM1 D-Sub9 RS485	XBT GT2000
XBT ZG919	XBT Z Adapter	Cable adapter COM1 D-Sub9 RS232	XBT GT2000
XBT ZG939	XBT Z Adapter	Cable adapter COM1 RJ45	XBT GT1000
XBT Z968 XBT Z9680 XBT Z9681	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Premium, Micro, Twido PLC	XBT GT1000/ GT2000
XBT Z9710	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Quantum PLC	XBT GT1000/ GT2000
XBT Z9711	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Momentum PLC	XBT GT1000/ GT2000
XBT Z908	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to derivation box TSXSCA62	XBT GT2000
XBT Z938	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to ATV drives or to Hub LU9GC3	XBT GT2000

Product Number	Product name	Description	XBT GT series
XBT Z918	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Premium Module SCY	XBT GT2000
XBT Z988	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Advantys STB	XBT GT1000/ GT2000
XBT ZGI232	XBT Z Isolation	Connect XBT GT COM1 port to an equipment and provide isolation	XBT GT2000
XBT ZGI485	XBT Z Isolation	Connect XBT GT COM1 port to an equipment and provide isolation	XBT GT2000
XBT ZGCOM1	Port Adapter	Connect XBT GT COM1 port to optional RS422 equipment	XBT GT2000
XBT ZGCOM2	Port Adapter	Connect XBT GT COM2 port to optional RS485 equipment	XBT GT2000
XBT ZG9731	XBT Z Cable	Connect XBT GT COM1 to Mitsubishi PLC A Series Link unit or to Rockwell DF1 Logix PLC	XBT GT2000
XBT ZG9772	XBT Z Cable	Connect XBT GT COM1 to Mitsubishi PLC Q Series Link Unit	XBT GT2000
XBT ZG9773	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC A Series CPU Unit	XBT GT2000
XBT ZG9774	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC Q Series CPU Unit	XBT GT2000
XBT ZG9775	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC FX Series CPU Unit	XBT GT2000
XBT ZG9740	XBT Z Cable	Connect XBT GT COM1 to Omron PLC Sysmac Link Series	XBT GT2000
XBT ZG9722	XBT Z Cable	Connect XBT GT COM1 to RS422 devices	XBT GT2000
XBT ZG9778	XBT Z Cable	Connect XBT GT COM1 with port adapter to Mistubishi PLC with Melsec 2 port adapter	XBT GT2000
XBT ZG979	Adapter		XBT GT2000
XBT ZG949	Adapter	Terminal RS422 block to connect XBT GT COM1 with port adapter to RS422 devices	XBT GT2000
XBT ZG9721	XBT Z Cable	Connect XBT GT1000 COM1 or XBT GT2000 COM2 to Siemens PPI PLC	XBT GT1000/ GT2000
XBT ZG9292	XBT Z Cable	Connect XBT GT COM1 to Siemens MPI PLC	XBT GT2000

Product Number	Product name	Description	XBT GT series
XBT Z918	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Premium Module SCY	XBT GT2000
XBT Z988	XBT Z Cable	Connect XBT GT COM1 port with XBTZ adapter to Advantys STB	XBT GT1000/ GT2000
XBT ZGI232	XBT Z Isolation	Connect XBT GT COM1 port to an equipment and provide isolation	XBT GT2000
XBT ZGI485	XBT Z Isolation	Connect XBT GT COM1 port to an equipment and provide isolation	XBT GT2000
XBT ZGCOM1	Port Adapter	Connect XBT GT COM1 port to optional RS422 equipment	XBT GT2000
XBT ZGCOM2	Port Adapter	Connect XBT GT COM2 port to optional RS485 equipment	XBT GT2000
XBT ZG9731	XBT Z Cable	Connect XBT GT COM1 to Mitsubishi PLC A Series Link unit or to Rockwell DF1 Logix PLC	XBT GT2000
XBT ZG9772	XBT Z Cable	Connect XBT GT COM1 to Mitsubishi PLC Q Series Link Unit	XBT GT2000
XBT ZG9773	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC A Series CPU Unit	XBT GT2000
XBT ZG9774	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC Q Series CPU Unit	XBT GT2000
XBT ZG9775	XBT Z Cable	Connect XBT GT COM1 to Mistubishi PLC FX Series CPU Unit	XBT GT2000
XBT ZG9740	XBT Z Cable	Connect XBT GT COM1 to Omron PLC Sysmac Link Series	XBT GT2000
XBT ZG9722	XBT Z Cable	Connect XBT GT COM1 to RS422 devices	XBT GT2000
XBT ZG9778	XBT Z Cable	Connect XBT GT COM1 with port adapter to Mistubishi PLC with Melsec 2 port adapter	XBT GT2000
XBT ZG979	Adapter		XBT GT2000
XBT ZG949	Adapter	Terminal RS422 block to connect XBT GT COM1 with port adapter to RS422 devices	XBT GT2000
XBT ZG9721	XBT Z Cable	Connect XBT GT1000 COM1 or XBT GT2000 COM2 to Siemens PPI PLC	XBT GT1000/ GT2000
XBT ZG9292	XBT Z Cable	Connect XBT GT COM1 to Siemens MPI PLC	XBT GT2000

Product Number	Product name	Description	XBT GT series
XBT Z9730 XBT Z9731	XBT Z Cable	Connect XBT GT COM1 with XBT Z adapter to Rockwell DF1 PLC	XBT GT1000
XBT Z9732	XBT Z Cable	Connect XBT GT COM1 with XBT Z adapter to Rockwell DH485 PLC	XBT GT1000/ GT2000
XBT Z9740	XBT Z Cable	Connect XBT GT COM1 with XBT Z adapter to Omron PLC Sysmac Link Series	XBT GT1000
XBT Z9720	XBT Z Cable	Connect XBT GT COM1 with XBT Z adapter to Siemens 3964/RK512	XBT GT1000/ GT2000

XBT GT Tool Connector

The following table presents the Tool Connector used with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT ZG915 (for PC Serial Port) XBT ZG925 (for PC USB Port)	Cable	Connects the XBT GT to a personal computer. Transfers screen data and user program(s).	XBT GT1000

XBT GT USB Connector

The following table presents the USB Connector used with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT ZG935	Cable	Connects the XBT GT to a personal computer. Transfers screen data and user program	XBT GT2000
XBT ZGUSB	Cable	Extends a USB Host Interface on a cabinet with waterproofness	XBT GT2000

XBT GT Software

The following table presents the XBT GT Software:

Product name	Description
Vijeo Designer (version 4.3 or higher)	Software used to create XBT GT unit project data. It is installed in a personal computer.

XBT GT Screen Protection Sheet

The following table presents the Screen Protection Sheet used with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT ZG61	Screen Protection Sheet	Dirt-resistant sheet used for the XBT GT's screen. The XBT GT's touch panel can be operated with this cover sheet attached. (5 sheets by pack)	XBT GT1000
XBT ZG62	Screen Protection Sheet	Dirt-resistant sheet used for the XBT GT's screen. The XBT GT's touch panel can be operated with this cover sheet attached. (5 sheets by pack)	XBT GT2000

XBT GT Spring Clip Fasteners

The following table presents the Spring Clip Fasteners used with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT Z3002 (set of 12 clips)	Spring Clip Fasteners	Fasteners to attach toolfree the XBT GT to a panel (for use only with a IP65 protection)	XBT GT1000/2000

XBT GT Compact Flash Memory Card Interface

The Compact Flash Memory Card is used for the following XBT GT unit:

- XBT GT2120
- XBT GT2130
- XBT GT2220
- XBT GT2330

This slot accepts a Compact Flash memory Card (CF Card):

- XBT ZGM64 (64 Megabytes)
 - XBT ZGM128 (128 Megabytes)
 - XBT ZGM256 (256 Megabytes)
 - MPCN00CEF00N (512 Megabytes)
-

Maintenance Options

The following table presents the optional maintenance items available with XBT GT:

Product Number	Product name	Description	XBT GT series
XBT ZGFIX	Screw Installation Fastener	Fasteners to attach the XBT GT to a panel. (4 fasteners per pack)	XBT GT1000/2000
XBT ZG51	Installation Gasket	Provides a moisture resistant seal when installing the XBT GT range. Same as the seal included in the XBT GT's original package.	XBT GT1000
XBT ZG52	Installation Gasket	Provides a moisture resistant seal when installing the XBT GT range. Same as the seal included in the XBT GT's original package.	XBT GT2000

Specifications

3

At a Glance

Overview

This chapter presents the different XBT GT specifications:

- General Specifications
- Functional Specifications
- Interface Specifications
- Part Numbers and Functions
- Dimensions

What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	General Specifications	33
3.2	Functional Specifications	38
3.3	Interface Specifications	45
3.4	Part Numbers and Functions	53
3.5	Dimensions	61

3.1 General Specifications

At a Glance

Overview

This section presents XBT GT general specifications:

- Electrical Specifications
 - Environmental Specifications
 - Structural Specifications
-

What's in this Section?

This section contains the following topics:

Topic	Page
Electrical Specifications	34
Environmental Specifications	35
Structural Specifications	37

Electrical Specifications

XBT GT Electrical Specifications

The following table presents the XBT GT's electrical specifications:

Specification	XBT GT1100 XBT GT1130	XBT GT2110	XBT GT2120 XBT GT2130 XBT GT2220 XBT GT2330
Input Voltage	24V DC		
Rated Voltage	19.2 V DC to 28.8 V DC		
Allowable Voltage Drop	≤ 1 ms	≤ 10 ms	≤ 5 ms
Power Consumption	≤ 7 W	≤ 18 W	≤ 26 W
In-Rush Current	≤ 50 A [The FWHM (Full-width, half maximum) value is approximately 50μs. (When exceeding 25A)]	≤ 30 A	
Voltage endurance between power terminal and frame ground (FG)	AC 500 V 20mA for 1 minute		
Insulation Resistance between power terminal and frame ground (FG).	20MΩ or higher at 500V DC	200MΩ or higher at 500V DC	

Environmental Specifications

Introduction

The following are the Environmental Specifications of XBT GT.

XBT GT Environment Specifications

The following table presents the XBT GT's environment specifications:

Specification	XBT GT1100 XBT GT1130	XBT GT2110	XBT GT2120 XBT GT2130 XBT GT2230 XBT GT2330
Ambient operating temperature (Cabinet interior & Panel face)	0°C to +50°C (32°F to 122°F) (1)		
Storage temperature	-20°C to + 60°C (-4°F to 140°F)		
Operating humidity	10%RH to 90%RH (Non condensing, wet bulb temperature: ≤ 39°C)		
Storage humidity	10%RH to 90%RH (Non condensing, wet bulb temperature: ≤ 39°C)		
Air purity (Dust)	≤ 0.1mg/m ³ (non-conductive levels)		
Pollution degree	Pollution degree 2		
Corrosive gases	Free of corrosive gases		
Atmospheric endurance (XBT GT operation altitude)	800hPa to 1,114hPa (2,000 meters [2187.22 yd.] (or lower)		
Vibration resistance	IEC61131-2 compliant ● Industry: 5 Hz to 9 Hz 3.5mm, 9 Hz to 150 Hz 1g.	IEC61131-2 compliant ● Industry: 10 Hz to 57 Hz 0.075mm, 57 Hz to 150 Hz 1g.	
Noise immunity (via noise simulator)	Noise voltage: 1000Vp-p. Pulse duration: 1μ sec. Rise time:1n sec.	Noise voltage: 1,200Vp-p. Pulse duration: 1μ sec. Rise time: 1n sec.	
Electrostatic discharge immunity	6kV contact (complies with EN 61000-4-2 level 3)		

Note: (1) The LCD displays of XBT GT1100/1130/2110/2120/2130/2220/2330 may occasionally blur when they are used for hours at over 40°C [104°F] ambient operating temperature. After the temperature returns to normal, the display will be restored to normal. The XBT GT's operation will not be affected even though the display is blurred.

CAUTION

RISK OF EQUIPMENT DAMAGE

Do not store the XBT GT in an area where the temperature is lower than the temperature recommended in the XBT GT unit's specifications. Doing so may cause the LCD display's liquid to freeze, which can damage the LCD. Also, if the storage area's temperature becomes higher than the specified level, the LCD's liquid may become isotropic, causing irreversible damage to the LCD. Therefore, only store the XBT GT in areas where temperatures are within the XBT GT unit's specifications and do not restrict nor block the XBT GT unit's rear-face ventilation slots.

Failure to follow this instruction can result in injury or equipment damage.

Air quality and Temperature requirements

Observe the following environmental requirements when using XBT GT:

- Do not operate or store the XBT GT where chemicals evaporate, or where chemicals are present in the air:
 - Corrosive chemicals: Acids, alkalines, liquids containing salt.
 - Flammable chemicals: Organic Solvents.

WARNING

RISK OF EXPLOSION OR ELECTRIC SHOCK

Do not allow water, liquids, metal, and wiring fragments to enter the XBT GT unit's case, since they can cause either a malfunction or an electric shock.

Do not use the XBT GT in an environment where flammable gases are present as it may cause an explosion.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Structural Specifications

Introduction

The following are the Structural Specifications of XBT GT.

XBT GT Structural Specifications

The following table presents the XBT GT's structural specifications:

Specification	XBT GT1100 XBT GT1130	XBT GT2110	XBT GT2120 XBT GT2130 XBT GT2220 XBT GT2330
Grounding	Observe local codes and standards. Ensure the ground connection has a resistance $\leq 100\Omega$ and that the ground wire has a cross section of at least 2mm or 14AWG.		
Rating (For front panel or installed unit)	Equivalent to IP65 (IEC 60529) (1) NEMA # 250 Type 4X/12		
External dimensions	W130 mm [5.12 in] x H104 mm [4.09 in] x D41 mm [1.61 in]	W167.5 mm [6.60 in] x H135 mm [5.32 in] x D59.5 mm [2.34 in]	
Weight	$\leq 0.4\text{Kg}$ (0.9lb)	$\leq 1.0\text{Kg}$ (2.20lb)	
Cooling Method	Natural air circulation		

Note: (1) The front face of the XBT GT unit, installed in a solid panel, has been tested using conditions equivalent to the standards shown in the specification. Therefore, prior to installing the XBT GT be sure to confirm the type of conditions that will be present in the XBT GT's operating environment. If the installation gasket is used for a long period of time, or if the unit and its gasket are removed from the panel, the original level of the protection cannot be guaranteed. To maintain the original protection level, replace the installation gasket every year.

3.2 Functional Specifications

At a Glance

Overview

This section presents XBT GT Functional Specifications:

- Display
 - Memory
 - Interfaces
-

What's in this Section?

This section contains the following topics:

Topic	Page
Display	39
Memory, Clock, and Touch Panel	42
Interface	43

Display

Introduction

The following are the XBT GT Display Specifications.

STN Display XBT GT unit

The following table presents the display specification of XBT GT unit with STN screen technology:

Specification	XBT GT1100 XBT GT1130	XBT GT2110	XBT GT2120 XBT GT2130	XBT GT2220
Type	Monochrome LCD	Monochrome (Blue mode) LCD	Monochrome (B&W) LCD	Color
Resolution (pixels)	320 x 240			
Active Display Area WxH (mm)	76.7 x 57.5		115.2 x 86.4	
WxH (in.)	3.02 x 2.26		4.54 x 3.40	
Colors	8 levels of gray)	16 gradations		4.096 colors
Backlight (1)	LED Backlight (Color: Amber; Service life: 50,000 h. [half of original brightness]) (Color: Red; Service life: 10,000 h. [half of original brightness])	CFL Backlight (Service life: 58,000 h. at 25°C and continuous operation [half of original brightness])		CFL Backlight (Service life: 75,000 h. at 25°C and continuous operation [half of original brightness])
Contrast Adjustment	8 levels of adjustment available via touch panel.			
Brightness Adjustment	2 levels of adjustment available via touch panel.	8 levels of adjustment available via touch panel.		
System Embedded Language Fonts (2)	ASCII: (Code page 850) Alphanumeric (including European characters) Chinese: (GB2312-80 codes) simplified Chinese fonts Japanese: ANK 158, Kanji: 6,962 (JIS Standards 1 & 2) (including 607 non-kanji characters) Korean: (KSC5601 - 1992 codes) Hangul fonts Taiwanese: (Big 5 codes) traditional Chinese fonts			
Character Sizes (2)	8 X 8, 8 X 16, 16 X 16 and 32 X 32 pixels fonts			

Specification	XBT GT1100 XBT GT1130	XBT GT2110	XBT GT2120 XBT GT2130	XBT GT2220
Font Sizes	Width can be expanded 1 to 8 times. Height can be expanded 1/2 and 1 to 8 times.			
8 x 8 pixels	40 Char. per row, x 30 rows			
8 x 16 pixels	40 Char. per row, x 15 rows			
16 x 16 pixels	20 Char. per row x 15 rows			
32 x 32 pixels	10 Char.per row x 7 rows			

Note:

- (1) Among backlight units there may be slight variations in illumination color, however, this does not effect the performance or quality of the XBT GT unit.
- (2) The display font will differ depending on which (language) character, or which size you select. Also, if Vijeo Designer 4.3 or later software is used, additional high quality fonts are available with 16x16 or larger characters.

**TFT Display
XBT GT unit**

The following table presents the display specification of XBT GT unit with TFT screen technology:

Specification	XBT GT2330
Type	TFT Color LCD
Resolution (pixels)	320 x 240
Active Display Area	
WxH (mm)	76.7x57.5
WxH (in.)	3.02x2.26
Colors	65.536 colors
Backlight (1)	CFL Backlight (Service life: 50,000 h. at 25°C and continuous operation [half of original brightness])
Contrast Adjustment	Not available.
Brightness Adjustment	8 levels of adjustment available via touch panel.
Language Fonts	ASCII: (Code page 850) Alphanumeric (including European characters) Chinese: (GB2312-80 codes) simplified Chinese fonts Korean: (KSC5601 - 1992 codes) Hangul fonts Taiwanese: (Big 5 codes) traditional Chinese fonts
Character Sizes (2)	8 X 8, 8 X 16, 16 X 16 and 32 X 32 pixel fonts
Font Sizes	Width can be expanded 1 to 8 times. Height can be expanded 1/2 and 1 to 8 times.
8 x 8 pixels	40 Char. per row, x 30 rows
8 x 16 pixels	40 Char. per row, x 15 rows
16 x 16 pixels	20 Char. per row x 15 rows
32 x 32 pixels	10 Char.per row x 7 rows

Note:

- (1) Among backlight units there may be slight variations in illumination color, however, this does not effect the performance or quality of the XBT GT unit.
- (2) The display font will differ depending on which (language) character, or which size you select. Also, if Vijeo Designer 4.3 or later software is used, additional high quality fonts are available with 16x16 or larger characters.

Memory, Clock, and Touch Panel

Memory

The following table presents the specification memory of each XBT GT unit:

Memory	XBT GT1100 XBT GT1130	XBT GT2000 series
Application Flash EPROM	8 Megabytes	16 Megabytes
Data Backup SRAM uses a lithium battery (1)	512 Kilobytes	512 Kilobytes
Application run DRAM	16 Megabytes	32 Megabytes
Legend:		
(1) A Lithium battery life is: <ul style="list-style-type: none"> • 10 years when the battery's ambient temperature is $\leq 40^{\circ}\text{C}$ (104F.). • 10 years when the unit's ambient temperature is $\leq 25^{\circ}\text{C}$ (77F.). When used for backup: (without main power): <ul style="list-style-type: none"> • Approximately 60 days, with a fully charged battery. • Approximately 6 days, with a 10% charged battery. 		

Clock

⚠ WARNING
UNINTENDED EQUIPMENT OPERATION
Variations in operating conditions and battery life can cause a clock error from -380 to +90 seconds per month. The user should monitor the time and adjust the time as needed to satisfy the system needs.
Failure to follow this instruction can result in death, serious injury, or equipment damage.

Touch Panel and Function Keys of XBT GT

The following table presents the touch panel and function keys of XBT GT unit:

Specification	XBT GT1000	XBT GT2000
Touch panel resolution	8 x 6 matrix 1 or 2 point push, selectable	Analog typing system 1024x1024 resolution, (Single point push selectable)
Function keys	6 switches	-

Interface

Introduction

All XBT GT displays are provided with a Serial Interface, and Tool Port or USB Connector.

Serial Tool Port Connector

The following table describes the Tool port of XBT GT1100/1130

Interface	Description
Tool Port Connector	Asynchronous TTL level nonprocedural interface command Used for transferring data user program to and from the Vijeo Designer and XBT GT.

Serial Interface COM1

The following table describes the Serial Interface of XBT GT1100/1130

Interface	Description
Serial interface COM1 RJ45	
Asynchronous Transmission	RS232C / RS485
Data Length	7 or 8 bits
Stop Bit	1 or 2 bits
Parity	None, Odd or Even
Data Transmission Speed	2,400bps to 115,200bps

The following table lists the Serial Interface of XBT GT2110/2120/2130/2220/2330 units.

Interface	Description
Serial interface COM1 D-Sub9	
Asynchronous Transmission	RS232C/RS422
Data Length	7 or 8 bits
Stop Bit	1 or 2 bits
Parity	None, Odd or Even
Data Transmission Speed	2,400bps to 115,200bps

**Serial Interface
COM2**

The following table lists the serial interfaces COM2 of XBT GT2110/2120/2130/2220/2330 units.

Interface	Description
Serial interface COM2 RJ45	
Asynchronous Transmission	RS485
Data Length	7 or 8 bits
Stop Bit	1 or 2 bits
Parity	None, Odd or Even
Data Transmission Speed	2,400bps to 12Mbps (except for XBT GT2110:115,200bps)

**Serial Interface
Ethernet**

The following table lists the serial interface Ethernet available for XBT GT1130/2130/2330:

Interface	Description
Ethernet RJ45	IEEE802.3, 10Base-T (XBT GT1000), 10Base-T/100Base-T (XBT GT2000)

**Serial Interface
USB and Memory
Card**

The following table lists the serial interface USB and Memory card available for XBT GT2000:

Interface	Description
USB TYPE-A x 1	USB 1.1 host I/F
CF Card slot (TYPE-II (except XBT GT2110))	Compact Flash

3.3 Interface Specifications

At a Glance

Overview

This section presents interface specifications of XBT GT units:

- Specification of serial interface COM1
 - Other interfaces
-

What's in this Section?

This section contains the following topics:

Topic	Page
Specifications of Serial Interface COM1	46
Specifications of Serial Interface COM2	51
Other Interfaces	52

Specifications of Serial Interface COM1

Introduction

This interface is used to connect:

- XBT GT1000 to remote equipment, via an RS232C or RS485 cable. The connector used is a RJ45-type connector.
- XBT GT2000 to remote equipment, via an RS232C or RS422 cable. The connector used is a D-Sub9 connector.

DANGER

RISK OF ELECTRIC SHOCK OR EQUIPMENT DAMAGE

When connecting an external device to the XBT GT with the SG terminal, be sure to check that no short-circuit loop is created when you setup the system.


- The XBT GT unit's Serial Port is not isolated. The #8 SG (XBT GT1100/1130 Signal Ground) terminal must be connected to remote equipment when the host (PLC) unit is not isolated. To reduce the risk of damaging the RS232C/RS485 circuit, make sure to connect the #8 SG (Signal Ground) terminal to the appropriate equipment.
- The SG (Signal Ground) and the FG (Frame Ground) terminals are connected inside the XBT GT unit.

Failure to follow this instruction will result in death, serious injury, or equipment damage.

XBT GT1100/ 1130 Serial Interface COM1

This interface is used to connect a RS-232C/RS485 serial cable to XBT GT. An RJ45 8-pin plug connector is used.

The following table describes the XBT GT1100/1130 pin's serial interface used with RS-232C/RS485 serial cable.

Pin Connection	Pin	Signal Name	Direction	Meaning
<p style="text-align: center;">Front</p> 	1	RxD	Input	Receive Data (RS232C)
	2	TxD	Output	Send Data (RS232C)
	3	Not connected	-	-
	4	D1	Output/Input	Transfer Data (RS485)
	5	D0	Output/Input	Transfer Data (RS485)
	6	RTS	Output	Request To Send
	7	Not connected	-	-
	8	SG	-	Signal Ground

⚠ WARNING

RISK OF UNINTENDED EQUIPMENT OPERATION AND EQUIPMENT DAMAGE

- Ensure that all connections to the communication ports on the bottom and sides of the unit are not putting excessive stress on the ports.
- Securely attach communication cables to the panel or cabinet.
- Use only RJ45 cables with a locking tab in good condition.
- Use RJ45 connectors with locking system.

An excessive weight or stress on communication cables may cause an equipment's disconnection and unintended equipment operation.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

 **WARNING**

RISK OF EQUIPMENT DAMAGE AND POWER LOSS


- Avoid excessive stress on the power cable to prevent accidental disconnection.
- Securely attach power cables to the panel or cabinet.
- Use the designated torque to tighten the unit's terminal block screws.
- Install and fasten unit on installation panel or cabinet prior to connecting Power Supply and Communication lines.

Excessive stress on the power connection or attempting to install a unit with the power cables connected may disconnect or cause damage to the power connections, which can cause short circuits, fire or incorrect operation.


Failure to follow this instruction can result in death, serious injury, or equipment damage.

**XBT GT2110/
2120/2130/2220/
2330 Serial
Interface COM1**

The following table describes the XBT GT2110/2120/2130/2220/2330 pin's serial interface with a D-Sub9 type connector via an RS232C cable.

Pin Connection	Pin	Signal Name	Direction	Meaning
	1	CD	Input	Carrier Detect
	2	RD(RXD)	Input	Receive Data
	3	RD(RXD)	Output	Send Data
	4	ER(DTR)	Output	Data Terminal Ready
	5	SG	-	Signal Ground
	6	DR(DSR)	Input	Data Set Ready
	7	RS(RTS)	Output	Request to Send
	8	CS(CTS)	Input	Send Possible
	9	CI(RI)/VCC	Input	Called status display/+5V5% Output 0.25A
	Shell	FG	-	Frame Ground (Common with SG)

The following table describes the XBT GT2110/2120/2130/2220/2330 pin's serial interface with a D-Sub9 type connector via an RS422 cable.

Pin Connection	Pin	Signal Name	Direction	Meaning
	1	RDA	Input	Receive Data A (+)
	2	RDB	Input	Receive Data B (-)
	3	SDA	Output	Send Data A (+)
	4	ERA	Output	Data Terminal Ready A (+)
	5	SG	-	Signal Ground
	6	CSB	Input	Send Possible B (-)
	7	SDB	Output	Send Data B (-)
	8	CSA	Input	Send Possible (A)
	9	ERB	Input	Data Terminal Ready B (-)
	Shell	FG	-	Frame Ground (Common with SG)

⚠ WARNING

RISK OF UNINTENDED EQUIPMENT OPERATION AND EQUIPMENT DAMAGE

- Ensure that all connections to the communication ports on the bottom and sides of the unit are not putting excessive stress on the ports.
- Securely attach communication cables to the panel or cabinet.
- Use only D-Sub9 cables with a locking system in good condition.
- Use D-Sub9 connectors with locking system.

An excessive weight or stress on communication cables may cause an equipment's disconnection and unintended equipment operation.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING

RISK OF EQUIPMENT DAMAGE AND POWER LOSS

- Avoid excessive stress on the power cable to prevent accidental disconnection.
- Securely attach power cables to the panel or cabinet.
- Use the designated torque to tighten the unit's terminal block screws.
- Install and fasten unit on installation panel or cabinet prior to connecting Power Supply and Communication lines.

Excessive stress on the power connection or attempting to install a unit with the power cables connected may disconnect or cause damage to the power connections, which can cause short circuits, fire or incorrect operation.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Specifications of Serial Interface COM2

Introduction

This interface that is used to connect the XBTGT2110/2120/2130/2220/2330 to the Remote Equipment, via RS485 cable. The connector used is a RJ45-8-pin type connector.

⚠ DANGER

RISKS OF ELECTRIC SHOCK OR EQUIPMENT DAMAGE

When connecting an external device to the XBT GT2000 with the SG terminal, be sure to check that no short-circuit loop is created when you setup the system.


- The XBT GT2000 unit's Serial Port is not isolated. The #8 SG (XBT GT2000 Signal Ground) terminal must be connected to remote equipment when the host (PLC) unit is not isolated. To reduce the risk of damaging the RS485 circuit, make sure to connect the #8 SG (Signal Ground) terminal to the appropriate equipment.
- The SG (Signal Ground) and the FG (Frame Ground) terminals are connected inside the XBT GT2000 unit.

Failure to follow this instruction will result in death, serious injury, or equipment damage.

XBTGT2110/ 2120/2130/2220/ 2330 Serial Interface COM2 with RS485 cable

This interface is used to connect a RS485 serial cable to XB GT2000. RJ45 8-pin plug connector is used.

The following table describes the XB GT2000 pin's serial interface used with RS485 COM2 serial cable.

Pin Connection	Pin	Signal Name	Direction	Meaning
	1	Not connected	-	-
	2	Not connected	-	-
	3	Not connected	-	-
	4	D1	Output/Input	Transfer Data (RS485)
	5	D0	Output/Input	Transfer Data (RS485)
	6	RTS	Output	Request To Send
	7	Not connected	-	-
	8	SG	-	Signal Ground

Other Interfaces

XBT GT Ethernet Interface

The Ethernet Interface is used for the following XBT GT unit:

- XBT GT1130
- XBT GT2130
- XBT GT2330

This interface complies with the IEEE802.3 standard for Ethernet 10BASE-T (XBT GT1000), 10BaseT/100Base-TX (XBT GT2000) connections.

The following table describes the LED colors and status:

LED	Contents
Orange	<ul style="list-style-type: none">● When the Power Supply is ON: LED lights up.● When sending or receiving: LED blinks.
Green	When linking: LED lights up.

XBT GT USB Interface

The USB Interface accepts a USB data transfer cable and is used for the following XBT GT unit:

- XBT GT2110
 - XBT GT2120
 - XBT GT2130
 - XBT GT2220
 - XBT GT2330
-

3.4 Part Numbers and Functions

At a Glance

Overview

This section presents the Part Number and Functions of XBT GT unit.

What's in this Section?

This section contains the following topics:

Topic	Page
Parts Identification and Functions	54
Terminal Configuration Switches	58

Parts Identification and Functions

Introduction

The following diagram show display the Parts Identification and functions of the XBT GT Unit:

XBT GT1100 and XBT GT1130 Parts Identification



Side	XBT GT1100 Part Identification	XBT GT1130 Part Identification
Front	<p>Diagram showing the front view of the XBT GT1100 unit. Callout A, B points to the display screen. Callout C points to the power button. Callout G points to the function buttons (F1-F6).</p>	<p>Diagram showing the front view of the XBT GT1130 unit. Callout A, B points to the display screen. Callout C points to the power button. Callout G points to the function buttons (F1-F6).</p>
Rear	<p>Diagram showing the rear view of the XBT GT1100 unit. Callout F points to the circular ventilation fan.</p>	<p>Diagram showing the rear view of the XBT GT1130 unit. Callout F points to the circular ventilation fan.</p>
Bottom	<p>Diagram showing the bottom view of the XBT GT1100 unit. Callout D points to the terminal block. Callout E points to the power input terminal. Callout H points to the power switch.</p>	<p>Diagram showing the bottom view of the XBT GT1130 unit. Callout D points to the terminal block. Callout E points to the power input terminal. Callout H points to the power switch. Callout I points to the power switch.</p>



Description of XBT GT1100/1130

This following table presents description of part identification for XBT GT1100/1130:

Part	Description
A	Display: displays User created screens and Remote Equipment Variables.
B	Touch Panel: performs screen change operations and sends data to the host (PLC).
C	Power LED: LED ON
D	Power Input Terminal Block: connects the XBT GT power cable's input and ground wires to the XBT GT.
E	Serial I/F (host I/F 8 pin RJ45): connects a RS-232C or RS485 (Serial) cable (from the host/PLC) to the XBT GT (Y Port).
F	Tool Port Connector: connects the Data Transfer Cable to the XBT GT.
G	Function Switches (R1 to R6): used for function keys.
H	RS485 Line Polarization.
I	Ethernet Interface (except for XBT GT1100): permits to connect the XBT GT unit (X Port) to PLC from a Ethernet cable.

XBT GT2000 series Parts Identification

Side	XBT GT2000 series Part Identification
Front	
Rear	

Side	XBT GT2000 series Part Identification
Left and Right	 <p>Left Right</p>
CF Card Cover Open	 <p>L M</p>

**Description of
XBT GT2000
series**

This following table describes the parts identification of XBT GT2000 series:

Part	Description
A	Display: displays User created screens and Remote Equipment Variables.
B	Touch Panel: performs screen change operations and sends data to the host (PLC).
C	Status LED: <ul style="list-style-type: none"> ● Green (lit): Normal operation (Power is ON) or OFFLINE operation. ● Orange (lit) (Green + red): Backlight burnout is detected. ● Orange (blinking) (Green + Red): During Software startup. ● Red (lit): When Power is turned ON ● Not lit: Power is OFF
D	Expansion unit Interface: Connects expansion units with communication features.
E	CF Card Access Lamp (except XBT GT2110): <ul style="list-style-type: none"> ● Green ON: The CF Card is inserted and the Cover is closed, or the CF Card is being accessed. ● Green OFF: The CF Card is not inserted or is not being accessed.
F	Ethernet Interface (10BASE-T/100BASE-TX) (except XBT GT2110/2220: RJ-45 connector is used, and the LED turns ON or OFF to indicate the current status. <ul style="list-style-type: none"> ● Green ON: Data transmission available. ● Green OFF: No connection or subsequent transmission failure. ● Yellow ON: Data transmission is occurring. ● Yellow OFF: No data transmission.
G	Power Input Terminal Block: connects the XBT GT power cable's input and ground wires to the XBT GT.
H	USB Interface (USB1.1): Connects a data transfer cable to XBT GT.
I	Serial Interface COM1: Connects a RS232C or RS422 (Serial) cable (from the host/2CC) to the XBT GT (COM1 port).
J	Serial Interface COM2: Connects a RS488 (Serial) cable (from the host/2LC) to the XBT GT (COM2 port).
K	Polarization Switch Selector.
L	CF Card Cover (except XBT GT2110): Covers the CF Card Slot. This cover must be closed when accessing to the CF Card.
M	CF Card Socket: Permits to insert the CF Card in this slot.

Terminal Configuration Switches

Introduction

The RS485 Line Polarization Selector Switch is available on:

- XBT GT1100
- XBT GT1130
- XBT GT2110
- XBT GT2120
- XBT GT2130
- XBT GT2220
- XBT GT2330


The CF Card Dip Switches are available on:

- XBT GT2120
- XBT GT2130
- XBT GT2220
- XBT GT2330

XBT GT Location RS485 Line Polarization Selector Switch

On XBT GT1100/1130 and XBT GT2110/2120/2130/2220/2330, the RS485 line polarization Selector Switch is located next to the RJ45 Serial Port.

The following illustration displays the location of the RS485 line polarization Selector Switch on XBT GT units:



**XBT GT
Parameters of
RS485 Line
Polarization
Selector Switch**


The following table explains XBT GT1100/1130 and XBT GT2110/2120/2130/2220/2330 units' RS485 Line Polarization parameters:

Selector Switch	Function	ON	OFF	Note
1	Controls the polarization of RS485 serial line.	RS485 Serial line is polarized (620 Ω pull up on D1 and 620 Ω pull down on D0).	No polarization.	The polarization shall be activated if Modbus protocol has to be implemented and no other equipment performs polarization on the bus.

**XBT GT Location
of CF card Dip
Switches**

On XBT GT2120/2130/2220/2330, the CF Card Dip Switches are located below the CF Card Cover.

The following illustration displays the location of the CF Card Dip Switches on XBT GT2120/2130/2220/2330:



XBT GT The following table explains XBT GT2120/2130/2220/2330 units' CF Card Dip
Parameter of CF Switches parameters:
Card Dip
Switches

Dip Switch	Function	ON	OFF	Note
1	This Dip switch setting controls the startup from a CF Card.			(*): Startup data is required in the CF Card.
	When there is no startup data in the XBT GT memory.	Startup is done from the CF Card(*) and the data is also transferred into the XBT GT memory.	A system message appears.	
	When there is valid startup data in the XBT GT memory.	Startup is done from the CF Card* and the XBT GT memory is updated.	Start up is done from the XBT GT memory.	
2	This Dip switch allows download application on XBT GT products.	Download is available.	Download is not available.	-
3	Reserved	-	-	-
4	This setting controls the forced closing of the CF Card cover.	Forced close enabled.	Forced close disabled.	Used when CF Card cover is damaged.

3.5 Dimensions

At a Glance

Overview

This section presents all the dimensions of XBT GT units.

What's in this Section?

This section contains the following topics:

Topic	Page
XBT GT1000 Series Dimensions	62
XBT GT2000 Series Dimension	65
Panel Cut dimension	69
Installation Fasteners	70


XBT GT1000 Series Dimensions

Introduction

The following dimensions are given in mm and inches and apply to all XBT GT Series units.


Dimensions

The following illustrations display the dimensions of XBT GT1100/1130:



Installation with Spring Clips


The following illustrations display the external dimensions of the XBT GT1100/1130 unit with Spring Clips:



Note: Spring Clip fasteners have to be ordered separately (ref. XBT Z3002)

Installation with Screw Fasteners

The following illustrations display the external dimensions of the XBT GT1100/1130 unit with Screw Fasteners:




XBT GT2000 Series Dimension

Introduction

The following dimensions given in millimeters and inches apply to all XBTGT2000 Series units.


Dimensions

The following illustrations display the dimensions of XBT GT2110/2120/2130/2220/2330:




Dimensions with Cables

The following illustrations displays the dimensions of XBT GT2110/2120/2130/2220/330 with cables.



Installation with Spring Clips

The following illustrations display the external dimensions of the XBT GT2110/2120/2130/2220/2330 unit with Spring Clips:







Note: Spring Clip fasteners have to be ordered separately (ref. XBT Z3002)

Installation with Screw Fasteners

The following illustrations display the external dimensions of the XBT GT2110/2120/2130/2220/2330 unit with Screw Fasteners:

mm
inch




Panel Cut dimension

Introduction

Create a panel cut-out and insert the XBT GT into the panel from the front.

Inserting a XBT GT

The following presents principle of panel cut, (example for XBT GT1000 series), dimensions are in mm and in inches:



Dimensions

The following table presents all panel cut's dimensions in function of XBT GT unit:

XBT GT	A (mm)	B (mm)	A (in.)	B (in.)	C (mm)	C (in.)
XBT GT1100	+1	+1	+ 0.04	+ 0.04	1.6 to 5.0	0.06 to 0.2
XBT GT1130	118.5 - 0	92.5 - 0	4.67 - 0	3.64 - 0		
XBT GT2110	+1	+1	+ 0.04	+ 0.04	1.6 to 5.0	0.06 to 0.2
XBT GT2120	156	123.5	6.14	4.86		
XBT GT2130	- 0	- 0	- 0	- 0		
XBT GT2220						
XBT GT2330						

Installation Fasteners

Introduction

Two types of fasteners are used to mount the XBT GT range:


- Screw Installation Fasteners,
- Spring Clips.

Quantities of fasteners to install XBT GT units.

XBT GT	Spring Clips	Screw Installation Fasteners (1)
XBT GT1100 XBT GT1130	2	4
XBT GT2100 XBT GT2120 XBT GT2130 XBT GT2220 XBT GT2330	2	4
(1) Delivered with XBT GT unit		

XBT GT Spring Clip Dimensions


The following illustration shows the dimensions of the Spring Clip in mm and in inch:



**XBT GT Screw
Installation
Fasteners
Dimensions**

The following illustration shows the dimensions of the Screw Installation Fasteners in mm and in inch:

mm
inch



Installation and Wiring



At a glance

Overview

This chapter describes the installation procedures and the wiring principles of XBT GT.

What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
4.1	Installation	75
4.2	Wiring Precautions	82
4.3	Tool Port Connector	91
4.4	Ethernet Cable Connector	96
4.5	CF Card	98
4.6	USB Port	101

4.1 Installation

Installation Procedures


Introduction

Before installing the XBT GT product into a cabinet or panel, read the instructions below.

The installation gasket and installation fasteners (Screw Installation Fasteners or Spring Clips) are required when installing the XBT GT.


Gasket setup requirements


The following table describes the Gaskets setup requirements to be taken:

Stage	Description
1	Before installing the XBT GT into a cabinet or panel, check that the Installation gasket is securely attached to the unit.
2	A gasket which has been used for a long period of time may have scratches or dirt on its surface, and could have lost much of its dust and drip resistance. Be sure to change the gasket once a year or when scratches or dirt become visible.
3	Do not insert the joint of the installation gasket in the corner of the XBT GT. Insert the joint only in the straight sections of the groove preferably at the bottom of the product. If you do it, the joint will be pulled so that it may cause the installation gasket to be torn.
4	To ensure a maximum level of moisture resistance to the installation gasket, make sure the gasket is inserted into the panel bottom face as shown in the following illustrational: 

Panel setup procedure

The following table describes the Panel setup procedure to be taken:

Stage	Description
1	Check that the installation panel or cabinet's surface is flat, in good condition and has no jagged edges. Also, if desired, metal reinforcing strips can be attached to the inside of the panel, near the Panel Cut, to increase the panel's resistance
2	Panel thickness (See Panel cut dimensions) depends on the XBT GT unit. Decide the panel's thickness based on the level of panel strength required. (1.6mm (0.06inch) to 10mm (0.4inch) for XBT GT1100/1130.)
3	Be sure that the ambient operation temperature and the ambient humidity are within their designated ranges. (When installing the XBT GT in a cabinet or enclosure, the term "ambient operation temperature" indicates the cabinet or enclosure's internal temperature.
4	Be sure that heat from surrounding equipment does not cause the XBT GT to exceed its standard operating temperature.
5	<p>When installing the XBT GT in a slanted panel, the panel face should not incline more than 30°.</p> 
6	When installing the XBT GT in a slanted panel, and the panel face inclines more than 30°, the ambient temperature must not exceed 40 °C. You may need to use forced air cooling (fan, A/C) to ensure the ambient operating temperature is 40°C or below.
7	When installing the XBT GT vertically, position the unit so that the Power Input Terminal Block is also vertical.
8	When installing the XBT GT in Enclosure type 4 compliant environment, use only the screw installation fasteners supplied with the XBT GT (installation brackets + attachment screws).

Stage	Description
9	<p>For easier maintenance, operation and improved ventilation, install the XBT GT at least 100mm [3.94 in.] away from adjacent structures and other equipment as shown in the following illustrational:</p>  <p>The diagrams illustrate the required clearance for an XBT GT unit. The left diagram shows a side view of the unit with a 100mm (3.94 in.) gap between the unit and the wall. The right diagram shows a top-down view of the unit with a 100mm (3.94 in.) gap between the unit and the surrounding structure on all four sides.</p>



Fasteners' Instructions



The following table describes the Fasteners' instructions to be taken:

Stage	Description
1	The minimum number of installation fasteners required to install a XBT GT unit is four (4) for Screw Installation Fastener's system.
2	The minimum number of installation fastener's required to install XBT GT unit is two (2) for Spring Clip system.

Spring Clips' Procedure

The following table describes how to install the XBT GT with Spring Clip:

Step	Action
1	Place the XBT GT on a level surface with the display panel facing downward.
2	Check that the XBT GT's installation gasket (See Regular Cleaning) is seated securely into the gasket's groove, which runs around the perimeter of the panel's frame.
3	Create the correct sized opening required to install the XBT GT, using the installation dimensions (See Panel cut-out dimensions) given.
4	<p>Insert the XBT GT (example: XBT GT1100/1130) into the panel cut-out:.</p> 
5	<p>Adjust the Spring Clips for the panel thickness:</p> <ul style="list-style-type: none"> ● 1.6 mm ≤ panel thickness ≤ 4 mm (position 1), ● 4 mm ≤ panel thickness ≤ 6 mm (position 2). 
6	Place the Spring Clips at the anchoring points:

Step	Action
7	<p>Lock the Spring Clips by pressing simultaneously on the top and the bottom with two fingers.</p> 
8	<p>To remove the Spring Clips:</p> <ul style="list-style-type: none">● Unlock the Spring Clips by pressing on the back: 

⚠ CAUTION




RISK OF LOSS OF SEAL


The gasket helps maintain the protection ratings (IP65, IP20) of the unit, and provides additional protection from vibration. It is strongly recommended that you use the installation gasket, since it absorbs vibration in addition to repelling water. Install the gaskets delivered with your XBT GT product.

Failure to follow this instruction can result in injury or equipment damage.

Installation with screw fasteners

The following table describes how to install the XBT GT with screw fasteners:

Step	Action
1	Place the XBT GT on a level surface with the display panel facing downward.
2	Check that the XBT GT's installation gasket (See Regular Cleaning) is seated securely into the gasket's groove, which runs around the perimeter of the panel's frame.
3	Create the correct sized opening required to install the XBT GT, using the installation dimensions (See Panel cut dimensions) given.
4	Insert the XBT GT (example: XBT GT1100/1130) into the panel cut: 
5	Insert the installation fasteners into the XBT GT 's insertion slots situated on the left and right side of the unit and they are made to slide to a back side. If the fasteners are not correctly attached, the XBT GT unit may shift or fall out of the panel: 
6	Be sure to insert installation fasteners in the recessed portion of an installation fastener's hole: 

Step	Action
7	<p>Use a Phillips screwdriver to tighten each fastener screw and secure the XBT GT in place. The necessary torque is 0.5 Nm (4.4 lb-in):</p> 

⚠ CAUTION

RISK OF LOSS OF SEAL

The gasket helps maintain the protection ratings (IP65, IP20) of the unit, and provides additional protection from vibration. It is strongly recommended that you use the installation gasket, since it absorbs vibration in addition to repelling water. Install the gaskets delivered with your XBT GT product.

Failure to follow this instruction can result in injury or equipment damage.

Note: The Screw Installation Fasteners are required for NEMA4 protection.

4.2 Wiring Precautions

At a glance

Overview

This section presents principle of XBT GT wiring.

What's in this Section?

This section contains the following topics:

Topic	Page
Connecting the Power Cord	83
Connecting the Power Supply	86
Grounding	88
Input/Output Line placement	90

Connecting the Power Cord

Introduction

Follow these instructions when supplying power to the XBT GT unit.

Note:

- When the Frame Ground terminal is connected, be sure the wire is grounded. Not grounding the XBT GT unit will result in excessive noise and vibration. Grounding is required to assure EMC level immunity.
- The Shield Ground (SG) and Frame Ground (FG) terminals are connected internally in the XBT GT unit.
- If your system is installed with the 24 VDC power connected to the Frame Ground (typical in systems such as fire protection), when connecting other devices, be sure the design of the overall system does not produce a short loop.

WARNING

RISK OF ELECTRIC SHOCK

- Be sure the power cord is unplugged from the power outlet when connecting the power terminals to the XBT GT unit .
- The XBT GT1000 series and the XBT GT2000 series use only 24V DC power. Using any other level of power can damage both the power supply and the XBT GT unit.
- Since the XBT GT is not equipped with a power switch, be sure to connect a power switch to the XBT GT's power supply.
- Be sure to ground the XBT GT's FG terminal. Failure to do so can lead to an electrical shock or XBT GT malfunction.


Failure to follow this instruction can result in death, serious injury, or equipment damage.

Power Cord Preparation

Note:


- Wherever possible, use wires that are 0.2 to 2.5 mm² (24 - 12 AWG) in size for the power cord, and twist the wire ends before attaching the terminals.
- If the conductor's end (individual) wires are not twisted correctly, the end wires may either short loop to each other, or against an electrode. To avoid it, use D25CE/AZ5CE cable-ends.
- The Conductor Type is solid or stranded wire.

The following illustration shows the conductor length:



Power Plug Illustration

The following illustration shows the Power Plug



The following table displays connection wires into the Power Plug:

Connection	Wire
+	24V
-	0V
FG	Grounded Terminal connected to the XBT GT chassis.

How to connect the Power Cord on XBT GT1100/1130

The following table explains how to connect the Power Plug:


Step	Action
1	Remove the Power Cord from the Power supply.
2	Remove the Power Plug from XBT GT.
3	Remove the vinyl cover of each of the Power Cord's wires.
4	Twist the wire ends.
5	Connect the wires to the Power Plug by using flat-blade screwdriver (Size 0.6 X 3.5)
6	Torque the mounting screws: 0.5 to 0.6 Nm (4.4 to 5.2 lb-in)
7	Replace the Power Plug to the Power Connector.

Note:

- Don't solder the wire directly to the power receptable pin.
- The power supply cord should be equivalent to the specification shown above. Be sure to twist the power cords together, up to the power plug, for EMC cancellation. (See illustration as shown below)

Example of Power Cord's illustration connection on XBT GT1100/1130

The following illustration displays a connection's example of the Power Cord on XBT GT1100/1130:



Connecting the Power Supply

Introduction

Follow these instructions when supplying power to the XBT GT unit.

Precautions

- Connect the power cord to the Power Connector on the side of the XBT GT unit using the Power Plug.
- Between the line and the ground, be sure to use a regulated power supply with a Class 2 Power Supply
- To increase the noise resistance, be sure to twist the ends of the power cord wires before connecting them to the Power Plug.
- The XBT GT unit's power supply cord should not be bundled with or kept close to main circuit lines (high voltage, high current), or input/output signal lines.
- Connect a lightning surge absorber to handle power surges.
- To reduce noise, make the power cord as short as possible.

WARNING

RISK OF EQUIPMENT DAMAGE AND POWER LOSS



- Avoid excessive stress on the power cable to prevent accidental disconnection.
- Securely attach power cables to the panel or cabinet.
- Use the designated torque to tighten the unit's terminal block screws.
- Install and fasten unit on installation panel or cabinet prior to connecting Power Supply and Communication lines.

Excessive stress on the power connection or attempting to install a unit with the power cables connected may disconnect or cause damage to the power connections, which can cause short circuits, fire or incorrect operation.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Diagram of the Power Supply Connections


The following displays the Power Supply Connections:



Note:

- Be sure to ground the surge absorber (E1) separately from the XBT GT unit (E2).
- Select a surge absorber that has a maximum circuit voltage greater than that of the peak voltage of the power supply.

The following displays the Lightning Surge Absorber connection:



Grounding

Introduction

Take the following precautions for grounding the XBT GT unit.

⚠ WARNING


RISK OF EQUIPMENT DAMAGE AND UNINTENDED EQUIPMENT OPERATION

Do not use common grounding, since it can lead to electrostatic damage and unintended equipment operation which may lead to an accident or machine breakdown.

Failure to follow this instruction can result in death, serious injury, or equipment damage.



Exclusive Grounding

Connect the FG terminal found at the Power Plug to an exclusive ground.



Common Grounding

If exclusive grounding is not possible, use a common connection point.



Procedure

When Grounding, make sure to follow the procedures given below.

Step	Action
1	Check that the grounding resistance is less than 100Ω. (1).
2	The SG and FG terminals are connected internally in the XBT GT unit.
3	When connecting the SG line to another device, be sure that the design of the system/connection does not produce a grounding loop.
4	The grounding wire should have a cross sectional area greater than 2mm ² (1). Create the connection point as close to the XBT GT unit as possible, and make the wire as short, as possible. When using a long grounding wire, replace the thin wire with a thicker wire, and place it in a duct.
5	If the equipment does not function properly when grounded, disconnect the ground wire from the FG terminal.

(1): Observe local codes and standards. Ensure the ground connection has a resistance of less than 100Ω. and that the ground wire has a cross-section of at least 2mm² or 14AWG. For details, contact your local Schneider Electric distributor.

Input/Output Line placement

Introduction

Input and output signal lines must be separated from the power supply cables for operating circuits.

If this is not possible, use a shielded cable and connect the shield to the XBT GT's FG terminal.

4.3 Tool Port Connector

At a Glance

Overview

This section describes the Tool Port Connector Installation.

What's in this Section?

This section contains the following topics:

Topic	Page
Presentation	92
USB Data Transfer Cable (XBT ZG925) - USB Driver Installation	93

Presentation

Introduction

The Data Transfer Cables (XBTZG915 and XBTZG925). See. *Parts Identification and Functions*, p. 54 can be attached to the Tool Port on XBT GT11** Series units to allow transferring of data from the computer to the XBT GT

⚠ WARNING


RISK OF ELECTRIC SHOCK

To prevent an electric shock, unplug the XBT GT unit's Power Cord from the Main Power Supply prior to attaching or detaching any connector(s) to or from the XBT GT.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Tool Port Connector Location

The following diagram shows the Tool Port Connector Location.

XBT GT Unit	Tool Port Connector Location
Rear face of: XBT GT1100 XBT GT1130	

USB Data Transfer Cable (XBT ZG925) - USB Driver Installation

Introduction The USB Data Transfer Cable is used to download data from a PC running Vijeo-Designer to the XBT GT unit. It connects to the Tool Port of the XBT GT.

Installation Requirements The PC must run on Microsoft Windows 2000 or Windows XP. You will need the installation CD for Vijeo-Designer.

CAUTION

RISK OF EQUIPMENT DAMAGE

Follow the procedure described below to prevent damage to the cable connector or the XBT GT.

- When connecting the USB Data Transfer Cable to the PC or to the XBT GT unit, insert the cable's connector at the correct 90° angle.
- When disconnecting the cable, make sure to hold the connector, not the cable itself.
- If the cable is unplugged from the port designated during installation and connected to a different port, the Operating System (OS) will not recognize the new port. Therefore, make sure to always use the port designated during installation.
- If the installation does not complete successfully, restart the PC and quit all resident applications before re-installing the software.

Failure to follow this instruction can result in injury or equipment damage.

**Installation
Procedure for
Window 2000**

Use the following procedures with Windows 2000:

Step	Action
1	Start Windows, and connect the XBTZG925 cable to your PC's USB port at one end, and to the XBT GT's tool port at the other end.
2	Insert the Vijeo-Designer CD into the CD-ROM drive.
3	The New Hardware Wizard dialog box appears. Click Next.
4	In the following dialog box, select Search for a suitable driver for my device [recommended] option, and click Next.
5	In the following dialog box, select Specify a location option, and click Next.
6	In the following dialog box, Click Browse then, select the Set2pl.inf file located in the CD-ROM's folder XBTZG925, and click Open.
7	The dialog box displays the driver for the XBTZG925. Click OK.
8	Confirm the wizard finds the driver for the following device: Telemecanique XBTZG925, and click Next.
9	Click Finish to complete the installation.

**Installation
Procedure for
Windows XP**

Use the following procedures with Windows XP:

Step	Action
1	Start Windows, and connect the XBTZG925 cable to your PC's USB port at one end, and to the XBT GT's tool port at the other end.
2	Insert the Vijeo-Designer CD into the CD-ROM drive.
3	The Found New Hardware Wizard dialog box appears. Select Install from a list or specific location (Advanced) and click Next.
4	In the following dialog box, select Include this location in the search, and click Browse.
5	From the Installation CD-ROM, select the XBTZG925 folder, and click OK.
6	In the Found New Hardware Wizard dialog box, click Next.
7	The name of the Telemecanique XBTZG925 driver now displays in the dialog box. Click Continue Anyway.
8	Click Finish in the following screen to complete the installation.

Post-Installation Check Execute the following check after installation:

Step	Action
1	In the Control Panel, click on System Properties and select Device Manager.
2	Confirm that Telemecanique XBTZG925 COM3 is listed below Ports [COM & LPT].

Changing the COM Port Number

The COM number 3 is assigned automatically by the operating system (OS). If the OS had previously allocated COM 3 or other numbers for devices such as Internal modems, IrDA ports, and so on, XBTZG925 is allocated to the next available COM number. However if required, you can change the COM port number.

Step	Action
1	In the Control Panel, click on System Properties and select Device Manager.
2	Click to expand the Ports [COM & LPT] folder, right-click the Telemecanique XBTZG925 COM 3 node, and then click Properties.
3	In the Telemecanique XBTZG925 [COM3] Properties dialog box, click the Port Settings tab, and click the Advanced button.
4	At the bottom of the Advanced Settings for COM 3 dialog box, select an unused number and click OK.
5	When the following Communication Port Properties dialog box appears, click Yes.

Troubleshooting The following table describe errors that may occur and their possible solutions:

Problem/Symptom	Solution
The USB cable is not recognized.	Connect the cable correctly, or restart you PC. Also, when connecting a USB hub, make sure to connect it directly to your PC's USB port.
The Plug and Play is not functioning correctly.	
You are unable to use the USB cable after connecting it to a USB hub.	The power supplied from the hub may be insufficient. Make sure the hub is self-powered.
	Connect the cable directly to the PC USB port.
After installation, a "?" is displayed when you try to confirm the cable's status via the Device Manager.	The driver has not been installed correctly. Uninstall the driver and re-install it.

Uninstalling the USB Driver

Unplug the USB Data Transfer Cable from the PC and double-click on the CD-ROM's DRemover2K.exe file to start the uninstallation process.

4.4 Ethernet Cable Connector

Presentation


Introduction

The XBT GT1130/2130/2330 come equipped with an IEEE802.3 compliant Ethernet Interface, that transmits data at 10Mbps or 100 Mbps.

Illustration of XBT GT Ethernet Cable Connector


The following illustration displays the location of the RJ45 Ethernet Cable Connector:

Ethernet Cable Connector



XBT GT1130 Bottom

Ethernet Cable Connector



XBT GT2130/2330
Right Side

Both the Ethernet connector and the COM1 serial connector on XBT GT1130 or COM2 serial port connector on XBT GT2130/2330 use RJ45 ports, therefore, DO NOT confuse them.

 **WARNING****RISK OF MATERIAL DAMAGE AND UNINTENDED EQUIPMENT OPERATION**

- Do not connect the serial cable to the Ethernet port.
- Do not connect the Ethernet cable to the serial port.
- Carefully observe the product markings distinguishing between the Ethernet and serial ports.

Since Ethernet Port and the serial port (RJ45) share the same type of plug, there is a risk of swapping the Ethernet line with the serial line. Improper connections may result in damage to the XBT GT, to remotely connected equipment, and may cause unintended equipment operation.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Note: It is recommended that your Ethernet network is installed by a trained and qualified person.

You may be able to use the 1:1 connection with a cross cable depending on the connected PCs and network cards. Make sure to use 1:1 connections with a hub or a switch.

4.5 CF Card

CF Card Installation and Removal

Introduction

The following XBT GT target machines support the use of CF cards.

- XBT GT2120
 - XBT GT2130
 - XBT GT2220
 - XBT GT2330
-

Precautions

When using the XBT GT Unit and a CF Card, follow the precautions below:

- Prior to inserting or removing a CF Card, be sure to turn the XBT GT unit's CF Card ACCESS switch OFF and to confirm that the ACCESS lamp is not lit. If you do not, CF Card internal data may be damaged or lost.
- Check that the CF Card DIP Switches setting are appropriate.
- While a CF Card is being accessed, NEVER turn OFF or reset the XBT GT, or insert or remove the CF Card. Prior to performing these operations, create and use a special XBT GT application screen that will prevent access to the CF Card.
- Prior to inserting a CF Card, familiarize yourself with the CF Card's front and rear face orientation, as well as the CF Card connector's position. If the CF Card is not correctly positioned when it is inserted into the Muilt Unit, the CF Card's internal data and the XBT GT unit may be damaged or broken.
- Be sure to use only CF Cards manufactured by Schneider Electric. XBT GT unit performance cannot be guaranteed when using another manufacturer's CF Card.
- Once XBT GT data is lost, it cannot be recovered. Since accidental data loss can occur at any time, be sure to back up all XBT GT screen and CF Card data regularly.

CAUTION

RISK OF EQUIPMENT DAMAGE




Be sure to follow the instructions given below to prevent the CF Card's internal data from being destroyed or a CF Card malfunction from occurring:

- DO NOT bend the CF Card.
- DO NOT drop or strike the CF Card against another object.
- Keep the CF Card dry.
- DO NOT touch the CF Card connectors.
- DO NOT disassemble or modify the CF Card.

Failure to follow this instruction can result in injury or equipment damage.


Inserting the CF Card

Use the following steps to insert the CF Card in the XBT GT2000 unit (except XBT GT2110).

Step	Action
1	<p>Slide the CF Card Cover in the direction shown here, then upwards to open the cover.</p> 
2	<p>Insert the CF Card in the CF Card Slot, until the ejector button is pushed forward.</p> 
3	<p>Close the cover. (As shown).</p> 
4	<p>Confirm that the CF Card Access LED turns ON. You cannot access to the CF Card with the CF Card cover opened. However, if the CF Card is being accessed, the access will be continued even if you open it on the way.</p>

Removing the CF Card

Simply reverse the steps shown in the previous "inserting CF Card" explanation. Prior to removing the CF Card, confirm that the CF Card Access LED is turned OFF. The following figure displays how to remove the CF Card:



CF Card Handling

The CF card has a life expectancy of 100,000 write cycles. Therefore, be sure to back up all CF Card data regularly to another storage media. (100,000 times assumes the overwriting of 500 kilobytes of data in DOS format).

The following table presents two methods to back up data.

If	Then	And
Your PC is equipped with a PC Card Slot	To view CF Card data on a personal computer, first, insert the CF Card into a CF Card Adaptor XBTZGADT.	Save data CF Card on the PC.
Your PC is not equipped with a PC Card Slot	Use a standard XBTZGADT type PC Card or CF Card reader.	Save data CF Card on the PC.

Note: Depending on the setup of your PC, it's possible that the Card reader may not operate correctly. The connection between a personal computer and CF Card reader has been tested using an Windows® compatible machine. Check that CF Card reader is correctly installed and configured. Please contact your PC or CF Card reader manufacturer directly for details.

4.6 USB Port

At a Glance

Overview This section presents the USB Port.

What's in this Section? This section contains the following topics:

Topic	Page
Presentation	102
USB Data Transfer Cable (XBT ZG935) - USB Driver Installation	103
USB Cable Clamp	106

Presentation

Introduction

The following XBT GT units have a USB port:

- XBT GT2110
- XBT GT2120
- XBT GT2130
- XBT GT2220
- XBT GT2330

Data transfer cable (XBT ZG935) can be attached to the USB port to allow transferring of data from the computer to the XBT GT.

WARNING

RISK OF ELECTRIC SHOCK

To prevent an electric shock, unplug the XBT GT unit's Power Cord from the Main Power Supply prior to attaching or detaching any connector(s) to or from the XBT GT.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

USB Data Transfer Cable (XBT ZG935) - USB Driver Installation

Important information

CAUTION

RISK OF EQUIPMENT DAMAGE

Follow the procedure described below to prevent damage to the cable connector or the XTG GT.

- When connecting the USB Data Transfer Cable to the PC or to the XBT GT unit, insert the cable's connector at the correct 90° angle.
- When disconnecting the cable, make sure to hold the connector, not the cable itself.
- If the cable is unplugged from the port designated during installation and connected to a different port, the Operating System (OS) will not recognize the new port. Therefore, make sure to always use the port designated during installation.
- If the installation does not complete successfully, restart the PC and quit all resident applications before re-installing the software.

Failure to follow this instruction can result in injury or equipment damage.

**Installation
Procedure for
Windows 2000**

Use the following procedure with Windows 2000:

Step	Action
1	Insert the Vijeo Designer Installation CD-ROM into your CD-ROM drive. If the installation menu comes up, click Exit to close the menu.
2	Connect the USB cable to the USB port on your PC.
3	When Windows detects the USB cable and displays the Found New Hardware Wizard, click Next.
4	Select Search for a suitable driver for my device, then click Next.
5	Select the Specify a location check box, then click Next.
6	Define the path and filename Z:\XBT ZG935\usbdlc.inf (Z is the drive letter of the CD-ROM drive) and click OK.
7	Make sure the hardware wizard has located the correct driver for the USB Link Cable (XBT ZG935) and click Next.
8	Once driver installation is complete, click Finish to exist the wizard, then take a following steps to make sure installation is successful. <ol style="list-style-type: none">1. On the PC, make sure the USB cable is physically connected to the USB port.2. On the desktop, right-click My Computer and click Properties.3. In the System Properties dialog box, select the Hardware tab, and then click Device Manager.4. In the Device Manager, the USB Link Cable (XBT ZG935) should display below the USB (Universal Serial Bus) controller.
9	Note: You can install the USB Link Cable Driver from the Installer menu: Click the USB Driver button and follow the instructions.

Installation Procedure for Windows XP

Use the following procedure with Windows XP:

Step	Action
1	Insert the Vijeo Designer Installation CD-ROM into your CD-ROM drive. If the installation menu comes up, click Exit to close the menu.
2	Connect the USB cable to the USB port on your PC.
3	When Windows detects the USB cable and displays the Found New Hardware Wizard, select Install from a list or specific location, then click Next.
4	Select the Search for the best driver in these location and select the Include this location in the search check box, then define the path:Z:\XBT ZG935\usbdlc.inf (Z is the drive letter of the CD-ROM drive) and click Next.
5	Click Next on the [New hardware detect wizard] dialog box.
6	Make sure the hardware wizard has located the correct driver for the USB Link Cable (XBT ZG935), then click Continue.
7	Note: You can install the USB Link Cable Driver from the Installer menu: Click the USB Driver button and follow the instructions.

Troubleshooting

The following table describe errors that may occur and their possible solutions:

Problem/Symptom	Solution
The USB cable is not recognized.	Connect the cable correctly, or restart you PC. Also, when connecting a USB hub, make sure to connect it directly to your PC's USB port.
Overcurrent occurred	
The Plug and Play is not functioning correctly.	
You are unable to use the USB cable after connecting it to a USB hub.	The power supplied from the hub may be insufficient. Make sure the hub is self-powered.
	Connect the cable directly to the PC USB port.
After installation, a "?" is displayed when you try to confirm the cable's status via the Device Manager.	The driver has not been installed correctly. Uninstall the driver and re-install it.



Uninstalling the USB Driver


Step	Action
1	Click the USB device icon "Stop USB link cable" in the Windows task tray and then click the command Stop USB Link Cable (XBT ZG935) for Windows 2000, or Safely remove USB Link Cable (XBT ZG935) for Windows XP.
2	When the Safe To Remove Hardware message box appears, remove the USB download cable.
3	Click OK to close the message box.

USB Cable Clamp

Attaching the USB Cable Clamp


Use the following procedures to attach the USB Cable Clamp:

Step	Action
1	<p>Insert the USB holder into the slot in front of the XBT GT unit's USB port and pull it down and forward.</p> 
2	<p>Pass the band of the USB cable clamp through the bridge of the USB holder.</p> 

Step	Action
3	<p data-bbox="440 201 1218 253">Insert the USB cable into the port. Fasten the band around the plug and secure it with the clamp.</p>  <p data-bbox="440 402 573 423">USB Holder</p> <p data-bbox="838 350 906 371">Clamp</p> <p data-bbox="865 440 985 461">USB Cable</p>

Release the USB Cable Clamp

Lower the tab and lift the clamp to release the plug as the following illustration:



Setting and Debugging



At a Glance

Overview

This part describes the settings available on the target machine as well as how to debug XBT GT unit.

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
5	Settings	111
6	Troubleshooting	121
7	Maintenance	129

Settings



At a Glance

Overview

This chapter presents the Settings to be configured on XBT GT unit.

What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
5.1	XBT GT Settings	113

5.1 XBT GT Settings

At a Glance

Overview This section describes the settings on all XBT GT units.

What's in this Section? This section contains the following topics:

Topic	Page
Types of Settings	114
Offline Settings	115
System Settings	118

Types of Settings

Introduction

You can use the Setting menu to configure the XBT GT unit.

Depending on how you use your XBT GT, you can display the Settings menu using three different methods:

- Use a switch,
- Touch the top-left corner of the panel when powering up,
- Touch three corners of the panel simultaneously while the application is running.

You can select which methods your application uses in the Vijeo-Designer editor's Target properties.

To call up Setting menu


the following table describes the steps in calling up the Setting menu:

Step	Action
1	<p>Set up the method for entering the Setting menu in the editor. You can set up any combination of the following methods for displaying the Setting menu.</p> <ul style="list-style-type: none"> ● Switch: create a switch and add the Configuration System Operation. ● Top-Left Corner: in the Target properties, set To Configuration to either Top Left Corner or Top Left/3 Corner. ● Touch three corners simultaneously: in the Target properties, set To Configuration to either 3 Corner or Top Left/3 Corner. <p>If you set To Configuration to None, and do not create a switch to display the Settings menu, then there would be no way of configuring the XBT GT unit at run time.</p>
2	Connect the XBT GT unit's power supply.
3	<p>Depending on what you set up in Step 1, you can display the Settings menu using one of the following methods:</p> <ul style="list-style-type: none"> ● Touch the switch set up with the Configuration system operation. ● Touch the top-left corner of the screen within ten seconds after the XBT GT unit begins starting up. ● Touch any three corners of the panel simultaneously. Vijeo-Designer Runtime restarts and displays the Settings menu.
4	The Settings menu contains two tabs: Offline and System. Click either tab to display its settings.


Offline Settings

Introduction The Offline settings cannot be changed while a user application is running.

Offline Tab The following illustration shows the Offline tab on XBT GT1000 unit:



The following illustration shows the Offline tab on XBT GT2000 unit:



Network Settings The following table describes how to change the network settings (IP address) on the XBT GT 1300 unit (except on XBT GT1100).

Step	Action
1	In the Settings menu, touch the Offline tab.
2	Touch the Network icon.
3	Touch any of the three fields (IP Address, Subnet Mask, or Default Gateway) and a keypad will appear.
4	Enter the desired network addresses.

Note: In order for changes to the network settings to take effect, the XBT GT will restart when you touch "To Run Mode" and return to the application.

Touch Buzzer The following table describes how to change the buzzer settings on the XBT GT unit.

Step	Action
1	In the Settings menu, touch the Offline tab.
2	Touch the Buzzer icon.
3	Touch the desired buzzer mode. The factory setting is When Press Touch object. <ul style="list-style-type: none">● None: Selecting this will turn the buzzer OFF.● When Press Touch Object: The buzzer will only sound when a Touch Object is touched.

Backlight Control

The following table describes how to change the backlight settings on the XBT GT unit.

Step	Action
1	In the Settings menu, touch the Offline tab.
2	Touch the Backlight icon.
3	<p>In the Backlight Control, define the backlight operations.</p> <ul style="list-style-type: none">● Wait: To extend the life of the backlight, you can set up the XBT GT so that it turns off the backlight when the panel is inactive (idle) for the defined period of time, (Idle means the XBT GT panel has not been touched). The factory setting for this item is OFF.● Enable Touch if Backlight is Burned Out: this setting defines whether the touch panel is enabled or disabled when a backlight burnout is detected. When this feature is cleared and the backlight burns out, touch inputs are ignored to prevent operation errors. the factory setting for this item is OFF.
4	To turn the backlight off automatically after a specified period of time, touch the Wait checkbox and then set the idle time.

Self Test

Runs test on the XBT GT unit to ensure its various hardware components are operating correctly.

Option

Configure the COM1 port as a power supply.


System Settings

Introduction


You can change System Settings while the user application is still running.

System tab

The following illustration displays System tab on XBT GT1000 unit:



The following illustration displays System tab on XBT GT2000 unit:



Stylus

This setting is not supported for XBT GT1100/1130 series units.

Date/Time

The following table describes how to change the date or time on the XBT GT unit.

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Date/Time icon.
3	Touch any of the Date or Time fields and a data entry keypad will display. Use this keypad to define the selected date or time setting.

Restart

The following table describes how to force the XBT GT unit to restart.

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Restart icon.
3	Touch the Restart button to restart the XBT GT unit.

Language

The following table describes how to select the language used by the XBT GT system (Settings menu and run-time messages) and user application.

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Language icon.
3	Touch the spin boxes to select the desired System and User Application languages. The languages available in the Language Settings are defined in the Vijeo-Designer editor.

Version Information

The following table describes how to access version information about the runtime and user application on the XBT GT unit.

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Ver.Info icon. Version Information displays the version number of the runtime and the version and build number of the editor that was used to design the user application.

Memory

The following table describes how to access information about the amount of memory available and the amount of memory currently being used.

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Memory icon. <ul style="list-style-type: none">● DRAM describes the amount of memory currently being used by the application.● Main Flash indicates the amount of internal memory (flash memory) required to store the runtime system files and the user application.

**Brightness/
Contrast Control**

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Brightness icon.
3	Touch the up/down arrows to adjust the brightness and contrast. Reducing the brightness and contrast could increase the life span of the backlight.

Option

Step	Action
1	In the Settings menu, touch the System tab.
2	Touch the Option icon.
3	Select Invert to reverse the black and white colors on the screen. In some projects and in some environments, inverting could make the application more visible and reduce eye-strain of operator working with the target machine.

Troubleshooting



At a Glance

Overview

This chapter describes how to find and resolve problems with the XBT GT unit.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Troubleshooting Checklists	122
Self Test List	126

Troubleshooting Checklists

Introduction

When a problem occurs, make sure to go through the checklist and follow the instructions given.

Here are the main potential problems which may occur when using the XBT GT unit are:

- Panel display is blank,
- Connected equipment cannot be used,
- XBT GT does not respond or responds very slowly,
- XBT GT beeps when powered on,
- Cannot change the date or time.

Note: If the following checklists do not solve your problem, please contact your local Schneider Electric vendor or the vendor who sold you the XBT GT unit.

Panel display is blank

The table below gives you some solutions to adopt if the XBT GT unit display is blank.

Step	Check/Operation	Solution
1	Are all Vijeo Designer screens downloaded to the XBT GT unit?	You may have to download again the screens again.
2	Is the Initial Panel ID set up correctly in Vijeo Designer?	Enter the Initial Panel ID in the Vijeo Designer editor and download again.
3	Is the unit using the correct rated voltage?	Verify the power supply connections and levels.
4	Is the power supply OFF or disconnected?	Follow the instructions in this manual for reconnecting the power supply.
5	Is the power lamp lit?	A blank power lamp may indicate a problem with the hardware.
6	Is the backlight lit?	The backlight may be burned out or there may be a problem with the unit. Contact your local Schneider Electric distributor, for backlight replacement.
7	Is the problem resolved?	If none of the previous steps fixed the blank panel display problem, then there is a problem with the hardware.

Connected equipment cannot be used

The table below presents how to run through the following steps when the XBT GT unit is failing to communicate with connected equipment.

Step	Check/Operation	Solution
1	Is the power supply OFF or disconnected?	Verify the power supply connections and levels.
2	Do the Driver and Equipment settings in Vijeo-Designer match the actual equipment you are trying to communicate with?	In the Vijeo Designer editor's Navigator window's Project tab, expand the I/O Manager node to enter the correct configuration settings for the Driver and Equipment nodes.
3	Is the communication cable connected correctly?	Refer to the associated protocol manual for information about cable diagrams.
4	Is the problem resolved?	If none of the previous steps fixed the communication problem, then there is a problem with the hardware.

XBT GT does not respond when touched The table below gives you some solutions to adopt if the XBT GT unit is either not responding when touched or if its response time is very slow.

Step	Check/Operation	Solution
1	Disconnect all the cables except the power cable.	-
2	Enter the Settings menu, touch the Offline tab and then touch the Self Test icon. Run the Touch Panel test.	If the test fails, there is a problem with the hardware.
3	Enter the Settings menu, touch the System Tab and then touch the Stylus icon. Calibrate the analog touch.	If the touch calibration is not possible, there is a problem with the hardware.
4	If touch response is slow, does it happen on a specific panel?	If the panel displays the values of a large number of equipment variables, you may want to redesign the panel and separate the variables into different panels and download again.
5	If touch response is slow, the target's CPU may be very busy communicating with external equipment.	<p>To resolve this problem, try each of the following in the Vijeo Designer editor and download again.</p> <ul style="list-style-type: none"> ● If you are using serial communication, make sure the communication speed between the target and equipment is optimized. ● In the equipment or scan group properties, reduce the Scan Rate to Slow. This will reduce the frequency of variable updates to 1000ms. ● If you use many equipment variables in application scripts, you may want to change the script to a panel script so that the variables are active only when the information is necessary. <p>If none of the above works, then you may have to reduce the number of external variables in the project. If none of the proposed options work, contact your Schneider Electric Technical Support for other methods of optimizing your project.</p>

Target beeps when powered ON

If the target beeps continually when you turn ON the power supply, then the system files on the XBT GT unit have become corrupted.

To resolve this problem, do the following: From the Vijeo Designer Start menu, use the Runtime Installer application and run Recovery on the target machine.

Cannot change the Date or Time

The following table gives you some solutions to adopt if you cannot change the date or time.

Problem	Solution
The date and time keeps reverting to a different date and time when you try to change the date or time. The lithium backup battery for the internal clock has probably run out of power.	To ensure that the backup battery is fully charged: <ul style="list-style-type: none"> ● Run the XBT GT unit continuously for 24 hours, (the battery need 96 hours to be recharged fully). ● Try to change the clock setting again.
If the error continues, the battery may need replacement.	Contact your local Schneider Electric distributor for service.

 WARNING

RISK OF BATTERY EXPLOSION

Do not attempt to replace the XBT GT battery. Incorrectly replacing the battery may result in the battery explosion next time it is used. Contact a Schneider Electric representative for the nearest Schneider Electric support center.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Note: The lifetime of the backup battery depends on the ambient temperature.

The expected battery life is 10+ years when:

- The battery ambient temperature is less than 40°C (104°F).
- Or the unit ambient temperature is less than 25°C (77°F).

Self Test List


Introduction

The XBT GT unit is equipped with a number of diagnostic features that can be used to check its system and interfaces for any problems.


Self Test

From the Settings menu, touch the Offline tab and then the Self Test icon. Self Test menu appears.

The following illustration shows the Self Test menu on XBT GT1000.



The following illustration shows the Self Test menu on XBT GT2000.



Details




The following table describes each test in the Self Test menu.

Test	Description
Char. Pattern	Checks the characters in each font set available on the XBT GT unit. Use this test when characters (usually 2-byte characters) do not display properly. OK appears if there is no error; NG appears if there is an error.
Disp. Pattern	Use this test when your drawings do not display properly.
Touch Panel	Tests the touch panel cells. Each cell highlights when it's pressed during the test.
COM 1	Checks to make sure the serial port (RS-232C and RS-485) is working properly. To run the check, you may need to connect a loopback cable (see below). OK appears if there is no error; an error message appears if there is an error.
COM 2	
Video Memory	Use this check to test the video memory (memory used for screen display). Run this test when the screen does not display properly. OK appears if there is no error; NG appears if there is an error.

Wiring for COM 1, COM 2 tests

When testing the serial port, depending on which port and which communication format you are testing, you may need to attach a loopback cable with wiring as defined below.

The following table displays the loopback cable wiring for XBT GT:

RS-232C	RS-422
<p>XBT GT1000 in COM1</p> 	<p>Not available.</p>
<p>XBT GT2000 in COM1</p> 	<p>XBT GT2000 in COM1</p> 
<p>-</p>	<p>XBT GT2000 in COM2 Not available</p>

Maintenance



At a Glance

Overview

This chapter explains how to maintain your XBT GT.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Regular Cleaning	130
Periodic Check Points	131
Replacing the Backlight	132

Regular Cleaning

Introduction

The regular cleaning is composed of:

- Cleaning the front panel,
 - Cleaning the Gasket and procedures.
-

Cleaning the display

When the surface or the frame of the display gets dirty, soak a soft cloth in water with a neutral detergent, wring the cloth tightly, and wipe the display.

Note:

- Do not use paint thinner, organic solvents, or a strong acid compound to clean the unit.
 - Do not use hard or pointed objects to operate the touch-screen panel, since it can damage the panel surface.
-

Cleaning the Gasket

The gasket protects the XBT GT and improves its water resistance.


A gasket which has been used for a long period of time may have scratches or dirt on it, and could have lost much of its water resistance. Be sure to change the gasket at least once a year, or when scratches or dirt become visible.

Inserting the Gasket

The gasket must be inserted correctly into the groove for the XBT GT's moisture resistance to be equivalent to IP65.

The upper surface of the gasket should protrude approximately 2mm [0.08 inch] out from the groove. Be sure to check that the gasket is correctly inserted before installing the XBT GT into a panel.

Note: Be sure the gasket's seam is not inserted into any of the unit's corners. Insert the joint only in the straight sections of the groove, preferably in the bottom section. Inserting it into a corner may lead to its eventually tearing.



Periodic Check Points

Introduction

To keep your XB GT unit in its best condition, please, check the following points periodically.

- XBT GT Operation Environment,
 - Electrical Specifications,
 - Related Items.
-

XBT GT1000/ 2000 Operation Environment

- The operating temperature is within the allowable range (0°C to 50°C) (32°F to 122°F)?
 - The operating humidity is within the specified range (10%RH to 90%RH), dry bulb temperature of 39°C (102°F) or less)?
 - The operating atmosphere is free of corrosive gases?
-

XBT GT1000/ 2000 Electrical Specifications

- The input voltage is appropriate?
 - XBT GT1000/2000: DC19.2V to DC28.8V.
-

Related Items

- Are all power cords and cables connected properly? Have any become loose?
 - Are all mounting brackets holding the unit securely?
 - Are there many scratches or traces of dirt on the installation gasket?
-

Replacing the Backlight

Introduction

The XBT GT1000/2000 units's backlight cannot be replaced by the customer. When the backlights need to be replaced, please contact your local XBT GT distributor.

WARNING

RISK OF EQUIPMENT DAMAGE AND UNINTENDED EQUIPMENT OPERATION

Do not create XBT GT touch panel switches for system functions that may cause injury and/or equipment damage if activated accidentally.

If the XBT GT unit's backlight burns out and the unit is not set to Standby Mode, the touch panel remains active. If the operator fails to notice that the backlight is burned out and touches the panel, unintended equipment operation can occur.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

How to determine if the Backlight is burned out

If your XBT GT unit's backlight suddenly turns OFF, use the following steps to determine if the backlight is actually burned out:

- If the XBT GT unit's "Backlight Control" is not set and the screen has gone blank, your backlight is burned out.
- If the XBT GT unit's "Backlight Control" is set to Standby Mode and the screen has gone blank, and touching the screen or performing another input operation does not cause the display to reappear, your backlight is burned out.

Index

